

Propulse® Mushroom Valves and Washers

Replacing the Mushroom Valve

The Mushroom Valve is specifically designed to prevent water flowing out of the reservoir whilst filling.

Should a replacement Mushroom Valve be required, please follow the steps below – This will help prevent possible damage to the water inlet valve.

- Remove the reservoir from the Propulse NG
- Remove the old Mushroom Valve from the reservoir and discard
- Insert a new Mushroom Valve into the reservoir
- Return the reservoir to the machine

